

# B

## Getting Started

### 1. What You Need

#### Connecting to One HDTV

- A desktop or laptop computer connected to the Internet
- The appropriate cable to connect your computer to your HDTV

Note: Depending on connection type, a connector may be needed.

#### Connecting to Multiple HDTVs

- A desktop or laptop computer connected to the Internet
- An HDMI Splitter with the appropriate number of ports for your HDTVs (see below for examples)
- The appropriate cables to connect your computer to the HDMI Splitter and the HDMI Splitter to your HDTVs

Note: Depending on connection type, a connector may be needed.





## 2. Purchasing Credits/Setting Up Account

- View [Plans and Pricing](#) to determine the best plan for you.
- Go to the Store to purchase credits, which are required to play Boom games.
- When you make your first purchase, you will be prompted to set up your Boom account, including selecting your login email address and password.
- Purchases will be made through PayPal, but a **PayPal account is not required.**

## 3. Playing a Game

- After logging in, click "Members Area" and then click "Play Game."
- Click the game you wish to play.

## Important Notes

- Boom Industries is not an IT nor an Audio/Video company. The following general setup guidelines are for your convenience only. We recommend consulting an IT or Audio/Video professional for your setup.
- Although we try to keep our current guidelines up to date, technology is always advancing so products listed may not be the newest on the market.
- Only Computers or Laptops running Mac OS X or Windows 10 and above are recommended.
- We highly recommend using Google Chrome, Mozilla Firefox, or Safari. Other browsers may not be supported.
- Computer should be set to "Full Screen" mode. Note: Disable your computer's screen saver and sleep mode.
- Set your computer's resolution to a 16:9 aspect ratio.
- Tablets are only recommended for home use because they usually lack a standard wired network port, requiring the use of a Wi-Fi connection, as well as an HDMI connector. Connection guidelines only work with HDTVs. Longer cable lengths affect video signal strength; use the shortest quality cables possible for the best results.



# Full Screen Mode

## Browsers

- **Google Chrome**
- **Mozilla Firefox**
- **Internet Explorer**
  - Press the F11 Key on the upper keys of the keyboard.
- **Edge**
  - Open Boom Industries website.
  - Click on the 3 horizontal dots in the upper right corner of the screen. In the drop-down menu select: "Open in Internet Explorer."
  - Once the window refreshes, press the F11 Key on the upper keys of the keyboard to open or close "Full Screen" mode.
- **Safari (Mac)**
  - Click on the green dot in the upper left hand corner to open "Full Screen" mode.
  - If the Toolbar Bar still remains at the top, then click on "View" in the toolbar. In the drop-down menu, you can un-check: "Always Show Toolbar in Full Screen" option.
  - **Note: The Toolbar will reappear for use by dragging your cursor near the top of the screen.**